



www.robnelsonboats.nz

These settings are our base set up and may vary slightly for local conditions. We recommend to adjust a few mm at a time to dial your boat in to the days conditions. Using our rig tension gauge, set up stay tension to suit our sails and rigs. **On Pocket luff mains set backstay so mast is straight. On luff ring mains pull backstay on so middle of mast stays straight and tip just bends aft so the main just comes off the back of mast at top luff ring.**

IOM SETTINGS	Wind Range	Water Conditions	Main Boom to Post		Main Twist at Measurement point	Jib Twist at Measurement Point	Main Camber	Jib Camber	Main Luff	Rig Tension
A Rig	Light to Med	Flat	5	60mm	55mm	35mm	15mm	10-15mm	Very Slack	8.5
		Waves	5-10mm	65mm	60mm	40mm	20mm	15mm	Just Tight	
A Rig	Med To Heavy	Flat	5-10mm	65mm	60mm	35mm	10mm	10mm	Tight	8.2
		Waves	10-15mm	70mm	65mm	45mm	25mm	15mm	Tight	
B Rig	Light to Med	Flat	5mm	60mm	55mm	40mm	15-20mm	15mm	Slack	8
		Waves	5-10mm	65mm	60mm	45mm	20-25mm	20mm	Just Tight	
B Rig	Med To Heavy	Flat	10mm	65mm	65mm	40mm	18-20mm	15mm	Just Tight	7.8
		Waves	10-15mm	68mm	65mm	45mm	18-22mm	25mm	Tight	
C Rig	Light to Med	Flat	15-20mm	60mm	45mm	45mm	20-25mm	25mm	Very Slack	7
		Waves	20-25mm	65mm	50mm	45mm	25-30mm	25mm	Just Tight	
C Rig	Med To Heavy	Flat	20-25mm	60mm	50mm	45mm	18-20mm	25mm	Slack	7
		Waves	25-35mm	70mm	55mm	45mm	20-25mm	25mm	Tight	

Aug-26